



EXPEDITION

SADDLE PACKS


SADDLE PACK (9L)

WEIGHT

CAPACITY

325 grams

9 litres



L1	4 cm	1.5 in
L2	31 cm	12.2 in
L3	41 cm	16.1 in
H1	15 cm	5.9 in
WIDTH	17 cm	6.7 in


SADDLE PACK (14L)

WEIGHT

CAPACITY

350 grams

14 litres



L1	9 cm	3.5 in
L2	33 cm	13 in
L3	48 cm	18.9 in
H1	16 cm	6.3 in
WIDTH	18 cm	7.1 in


SADDLE PACK (17L)

WEIGHT

CAPACITY

425 grams

17 litres



L1	9 cm	3.5 in
L2	35 cm	13.8 in
L3	52 cm	20.5 in
H1	18 cm	7.1 in
WIDTH	19 cm	7.5 in

MINIMUM CLEARANCE

- A** 9L Saddle Packs require 18 cm / 7.1 in between the saddle rails and tyre. 14L and 17L packs require 20 cm / 7.9 in.
- B** 5 cm / 2 in of seatpost required for 9L packs, 8 cm / 3.1 in for larger models.
- C** If possible, flip the seat post collar so the bolt is on the opposite side of the post to the saddle pack. This avoids wear and tear on the base of the pack.

